

The **WingIt** Fastening Technology works in all hollow wall construction. WingIts require a 1.25" hole be drilled into the wall substrate. WingIts are self-waterproofing and self-structural and will not loosen or lose their structural integrity. Fasten the WingIt to the grab bar to locate the hole position. Drill the holes, remove the backing from the sealing gasket, insert in hole, remove grab bar, back off screw and push to release WingIt gripping fingers, then tighten screw and then reinstall grab bar.

CTHS114, Carbide hole saws are available for tile walls - rated at 40 holes in wall tile.

